



Byte-addressable memory = mutable byte array



Multi-byte values in memory

Store across contiguous byte locations.




Bit order within byte always same. Byte ordering within larger value?

Data, addresses, and pointers

address = index of a location in memory

pointer = a reference to a location in memory, represented as an address stored as data



Endianness

In what order are the individual bytes of a multi-byte value stored in memory?

most significant byte					I	leas	t si	igni	fica	nt by	/te
30 29 28 27 26 25 2	4 23 22 21 20 19 18 17 16	15 14 13 12 11	10	98	7	6	5	4	3	2	1 0
2A	В6	00						0	B		
Address Conte	nts Little Endian:	least signifi	can	t by	te	fir	st				
03 22		· byte at low a									
02 B6	 high orde 	 high order byte at high address 								1	
01 00	 used by x86 	• used by x86 ,									
00 01											
Address Conte	nts Big Endian: m	ost significa	ant	byte	e fi	rst	:			-	/
03 OF	high orde	r byte at low	add	ress							
02 00		 low order byte at high address 									
01 Вб	 used by net 	works, SPARC,									
00 22											
					Pro	ogran	nmin	ig wi	th M	emory	

C: Variables are locations


Compiler maps variable name \rightarrow location. Declarations do not initialize!

int x; // x @ 0x20
int y; // y @ 0x0C


x = 0; // store 0 @ 0x20


// store 0x3CD02700 @ 0x0C
y = 0x3CD02700;


// 1. load the contents @ 0x0C
// 2. add 3
// 3. store sum @ 0x20
x = y + 3;




Programming with Memory 13












*p = a[1] + 1;





C: Array allocation




C: Array access


Basic Principle

 $T \quad A[N];$

Array of length N with elements of type T and name A Identifier A has type T*



ex




0		'\0'		
Name:	zero	Name:	null character	
Type:	int	Type:	char	
Size:	4 bytes	Size:	1 byte	
Value:	0x00000000	Value:	0x00	
Usage:	The integer zero.	Usage:	Terminator for C strings.	
NULL				
NIIT.T.				
NULL Name:	null pointer / null refer	ence / null addre	SS	
	null pointer / null refer void*	ence / null addre	SS	
Name:	•	·		
Name: Type:	void*	64-bit architectu		
Name: Type: Size:	void* 1 word (= 8 bytes on a	64-bit architectu	re)	

Is it important/necessary to encode the null character or the null pointer as 0x0?


What happens if a programmer mixes up these "zeroey" values?

Programming with Memory 45

Addr		Perm	Contents	Managed by	Initialized	
2 [№] -1 ↑						
	Stack	RW	Procedure context	Compiler	Run time	
	↑					
	l Heap	RW	Dynamic data structures	Programmer, malloc/free, new/GC	Run time	
	Statics	RW	Global variables/ static data structures	Compiler/ Assembler/Linker	Startup	
	Literals	R	String literals	Compiler/ Assembler/Linker	Startup	
	Text	Х	Instructions	Compiler/ Assembler/Linker	Startup	
0				Programming	with Memory 50	



C: Dynamic array allocation



C: Array of pointers to arrays of ints

